

# **EHTHERFOX**

Quickstart Guide

V1.0.0

Etherfox – QUICKSTART GUIDE sales@granitedevices.com

# Setup

fr

		r r r r r r r r r r r r r r	
ltem	Description		Connector
1	Ethercat LEDs		
2	EtherFox status LEDs		
2	Ethorcat Port 0		V1

2	EtherFox status LEDs	
3	Ethercat Port 0	X1
4	Ethercat Port 1	X2
5	Rotary switch	
6	Micro USB connector (Enabled only when Rotary is set to 0)	X3
7	Simplemotion bus port	X4
8	Power supply connector (24VDC)	X5

# **Connect Ethercat**

Connect Ehernet cable from Ethercat Master to Etherfox Ethercat Port 0 –connector (X1).

Ethercat master is typically PC or PLC with Ethercat master software.

# **Connect Simplemotion**

Connect Simplemotion cable from Etherfox bus port (X4) to slave drive Simple motion port.

# Connect Power Supply

Do not connect the cable when power supply is ON.

Connect 24VDC power supply to Etherfox X5 connector.

#### Configure drives using USB-connector

- 1. Connect USB cable between EtherFox USB port (X3) and PC USB host port
- 2. Select position 0 form rotary switch
- 3. Power up the device and drives
- 4. Start Granity software and select USB-COM port
- 5. Configure drives using Granity (https://granitedevices.com/wiki/Granity)
- 6. Exit Granity
- 7. Select rotary position that indicates the number of drives connected to Simplemotion bus
- 8. Disconnect USB cable

# Configuring Etherfox with Twincat 3

Twincat installation can be read from Beckhoff information system documentation and is not described in this document.

### Copy description file

Copy EtherFOX.xml description file to Twincat installation directory\*.

→ This PC → Local Disk (C:) → TwinCAT → 3.1 → Config → Io → EtherCAT

\*Installation directory may vary depending on installation settings

Reload Device Descriptions from using TWINCAT dropdown menu from Twincat.



## Create a Project

Create new project.

Scan devices.

EtherFox Quickstart - Microsoft Visual Studio         FILE       EDIT       VIEW       PROJECT       BUILD       DEBUG       TWINCAT       TWINSAFE       P         Image: Image									
🐘 🛄 💋 🌂 🎯 🥘 🐾 🛛 <local> 🗾 🗸</local>									
Solution Explorer		<b>-</b> ₽ ×							
© ⊃ ☆ 'o - i	4								
Search Solution Explorer (C	trl+")	- م							
<ul> <li>Solution Enerrox Quickstatt (1 project)</li> <li>EtherFox Quickstatt</li> <li>SYSTEM</li> <li>MOTION</li> <li>PLC</li> <li>SAFETY</li> <li>C++</li> <li>I/O</li> </ul>									
🚹 Mappii	Add New Item	Ins							
1	Add Existing Item	Shift+Alt+A							
	Export EAP Config File								
~	Scan								
۵	Paste	Ctrl+V							
	Paste with Links								

Append NC- configuration to Twincat Project.

EtherCAT drive(s) adde	Ŀ	×
Append linked axis to:	NC - Configuration	OK
	UNC - Configuration	Cancel

# Select Operation mode

Set drive operation mode from Drive settings

4	☑ I/O
	▲ 📲 Devices
	🔺 🗮 Device 1 (EtherCAT)
	🚔 Image
	🚔 Image-Info
	SyncUnits
	Inputs
	Outputs
	🕨 🛄 InfoData
	Term 1 (EK1200)
	Drive 4 (EtherFOX)
	Module 1 (csv - axis)
	🔺 🛄 Inputs
	🔁 Error Code
	📂 Status Word
	🚰 ActualPosition
	Outputs
	WcState
	👂 🛄 InfoData
	Mappings
	NC-Task 1 SAF - Device 1 (EtherCAT) 1
	🚟 NC-Task 1 SAF - Sample_PTP_Move Instance

Set operation mode value from DC page to DC-Synchron

General	EtherCAT	DC	Process Data	Slots	Startup	CoE - Online	Online	NC-A: Online	NC-A: Functions
Operation Mode:				DC-S	ynchron			$\sim$	
					Adva	anced Settings.			

# Configuring number of drives

Set number of drives from Slots page. Select axis from slot and select csv – axis from right panel. Use middle buttons to select module to a slot.

eneral EtherCAT DC	Process Data Slots	Startup CoE	- Online (	Online			
Slot Slot Axis 0 Axis 1 Axis 2 Axis 3 Axis 4 Axis 5 Axis 6 Axis 7	Module csv - a	is	<	Module	ModuleIdent 0x00319800	Description csv	
Download SlotCfg	(l->P)			Create proje	ect specific XM	IL File	•

# Configure Encoder settings

Select Encoder settings from Axis menu.

<ul> <li>MOTION</li> <li>NC-Task 1 SAF</li> <li>NC-Task 1 SVB</li> <li>Image</li> <li>Tables</li> </ul>									
Objects									
▲ ⊒a Axes									
Axis 1									
👂 🐥 Enc									
▷ ➡L Drive									
🛌 Ctrl									
👂 🛄 Inputs									
Outputs									
Axis 2									
🔺 💘 Enc									
👂 🛄 Inputs									
Outputs									
▷ 🛥 📕 Drive									
🛌 Ctrl									
Inputs									
Outputs									

Set following values to Encoder parameters:

Encoder Scaling Factor value	0.0140625
Encoder Mask (maximum encoder value)	0x3FFFFFF
Encoder Sub Mask (absolute range maximum value)	0x00006400

Parameter	Offline Value
Encoder Evaluation:	
Invert Encoder Counting Direction	FALSE
Scaling Factor Numerator	0.0140625
Scaling Factor Denominator (default: 1.0)	1.0
Position Bias	0.0
Modulo Factor (e.g. 360.0°)	360.0
Tolerance Window for Modulo Start	0.0
Encoder Mask (maximum encoder value)	0x3FFFFFF
Encoder Sub Mask (absolute range maximum value)	0x00006400
Reference System	'INCREMENTAL'
Limit Switches:	
Soft Position Limit Minimum Monitoring	FALSE
Minimum Position	0.0
Soft Position Limit Maximum Monitoring	FALSE
Maximum Position	0.0
Filter:	
Homing:	
Other Settings:	

Axis Type should be CANopen DS402.

Link to PLC is appended only if a PLC item is appended to project and is not necessary for testing

eneral	Settings	Parameter D	ynamics 0	nline Function	s Coupling	Compensation				
Link To	o I/O		Drive 1 (E	therFOX) # A						
Link To	PLC									
Axis Type: CANopen DS402/Profile MDP 742 (e.g. EtherCAT CoE Drive) ~										
Unit: mm 🗸 Display (Only)										
			Position:	μm		Modulo				
Velocity: mm/min										
Resul	t									
Positi	ion:	Velocity:		Acceleration:	Jerk	:				
mm		mm/s		mm/s2	mm	/s3				
- Axis C	Cycle Time	/ Access Divide	r							
Divid	er:	1	<b>*</b>	Cycle Time (m	s): 2.0	00				

# Configure Axis parameters

Configure axis limits and motion parameters to match your drive configuration values.

Set limit values to less or equal to drive configuration parameters to avoid drive faults.



Genera	I Settings	Parameter	Dynamics	Online	Functions	Coup	oling Compensation		
	Parameter						Offline Value		
-	Maximum	Dynamics:							
	Reference	Velocity		500.0					
	Maximum	Velocity					400.0		
	Maximum	Acceleratio	n				10000.0		
	Maximum	Deceleratio	n				10000.0		
-	Default Dy	namics:							
	Default Ac	celeration					1000.0		
	Default De	celeration					1000.0		
	Default Jer	k					1150.0		
-	Manual Me	otion and H	oming:						
	Homing Ve	elocity (towa	ards plc can	n)			30.0		
	Homing Ve	elocity (off p	olc cam)				30.0		
	Manual Ve	locity (Fast)					400.0		
	Manual Ve	locity (Slow)	)				100.0		
	Jog Increm	ent (Forwar	d)				5.0		
	Jog Increm	ent (Backw	ard)				5.0		
+	Fast Axis St	top:							
+	Limit Swite	:hes:							
+	Monitoring	g:							
+	Setpoint G	enerator:							
+	NCI Param	eter:							
+	Other Setti	ngs:							

# Activate current configuration

Activate current configuration and set Run mode

EtherFox Quickstart - Microsoft Visual Studio	
FILE EDIT VIEW PROJECT BUILD DEBUG TWINCAT TWINSAFE	
- 💿 - 💿   🎦 - 📩 - 😩 🔛 📲   品 🗇 🏦   ジ - ペ -   🕨 Attach	•
🔋 🔛 🖾 🗢 🔨 🌀 [ 🧑 🐾 🛛 <local> 🔹 🗸</local>	
Sol Activate Configuration	>

Check that InputToggle variable chages states between 0 and 1.

<ul> <li>C++</li> <li>I/O</li> <li>Devices</li> <li>Device 2 (EtherCAT)</li> <li>Image</li> <li>Image-Info</li> <li>SyncUnits</li> <li>Inputs</li> <li>Outputs</li> <li>InfoData</li> </ul>	Name  Firror Code  Status Word  ActualPosition  WcState  InputToggle  State  Chn0	Online 0 X 4641 X 0 X 0 X 1 8 192.168.0.1 0
Gutputs      Inputs      Inputs	AdsAddr	192.168.0.1
<ul> <li>InfoData</li> <li>Drive 1 (EtherFOX)</li> </ul>	🔁 Chn0 🚰 DcOutputShift	0 X 610300
<ul> <li>Module 1 (csv - axis)</li> <li>Inputs</li> <li>Error Code</li> <li>Status Word</li> </ul>	PcInputShift Control Word PragetVelocity	X 3389700 X 6 X 0

Select Axis menu item from MOTION and select Online page

Solution Explorer 🔹	Ψ×	EtherFox Quickstart 🤕 🗙
○ ○ 습   'o - 司   ≠ <mark>-</mark>		General Settings Parameter Dynamics Online Functions Coupling Compensation
Search Solution Explorer (Ctrl+")  Solution 'EtherFox Quickstart' (1 project)  SYSTEM  MOTION  MOTION  MOC-Task 1 SAF  Tables  Compared  Dojects  MOTION  Search Se	<u>- م</u>	O.00000         Setpoint Position:         [mm]           Lag Distance (min/max):         [mm]         Actual Velocity:         [mm/s]           0.0000 (0.000, 0.000)         0.0000         0.0000         Setpoint Velocity:         [mm/s]           0.0000 (0.000, 0.000)         0.0000         0.0000         0.0000         0.0000           Override:         [%]         Total / Control Output:         [%]         Error:         0 (0x0)           Status (log.)         Status (phys.)         Enabling         Coupled Mode         Controller         Set           Calibrated         Moving Fw         In Target Pos.         In Pos. Range         Feed Bw         Feed Bw
Axis 1      Axis 1      Axis 1      Axis 1      Axis 1      Dive     Outputs      Ari     Drive     Ctrl      Dive     Inputs      Outputs      Outputs      Dutputs      Dutputs      Dutputs      Ctrl		Controller Kv-Factor:[mm/s/mm]Reference Velocity:[mm/s]1 $\downarrow$ 500 $\downarrow$ Target Position:[mm]Target Velocity:[mm/s]0 $\downarrow$ 00F1F2F3F4F5F6F8F9

Make sure that motor can run safely before enabling drive. Make sure that there nothing connected to Axis on test phase.

Axis torque can be enabled using Enable sections Set - button.

Set Enabling	×
Controller	OK
Feed Bw	Cancel
Override [%]:	
100	All

Axis status should be Ready and Not moving.

General	Settings	Parameter	Dynamics	Online	Function	ns	Coupling	Compe	nsation
0.0000 Setpoint Position:						[mm] 0.0000			
Lag Dis	Lag Distance (min/max):         [mm]         Actual Velocity:         [mm/s]         Setpoint Velocity:           0.0000         (0.000, 0.000)         0.0000         0.0000         0.0000         0.0000						elocity:	[mm/s] 0.0000	
Overrid	e:	ڑ] 100.0000 \$	[] Total / C	Control Ou 0.0	tput: [ )0 / 0.00	% %	Error:		0 (0x0)
Statu Re Cal	s (log.) ady ibrated s Job	✓ NOT Mo Moving I Moving I	ving C Fw C Bw C	tatus (phy ] Coupled ] In Targe ] In Pos.	rs.) IMode etPos. Range		Enabling Contro Feed Feed	oller Fw Bw	Set
Controller Kv-Factor: [mm/s/mm] Reference Velocity: [m 500						[mm/s]			
Target 0	Position:		[mm] ↓	Ta O	arget Velo	city	<i>r</i> :		[mm/s]
 F1	F2	+ F3	<b>++</b> F4	∲ F5	F	<b>9</b> 6		® F8	→• F9

Use F1 / F2 buttons to Jog axis.

Disable controller after test session.

Set Enabling	×
	OK
Feed Bw	Cancel
0verride [%]:	
100	All

# **Drive Inputs**

### Actual Position

CiA402 Specific actual position.

### Status Word

CiA402 Specific status word bits. No vendor specific values.

### Error Codes - 0x603

Drive and Etherfox error codes can be read from Error Code input.



- Module 1 (csv axis)
  - 🖌 🛄 Inputs
    - 🔁 Error Code
    - 😤 Status Word
    - 😤 ActualPosition
  - 👂 📑 Outputs

Etherfox bridge error codes listed below:

Error Code (HEX)	Description			
0xEC01	Invalid gain or division value in drive configuration parameters			
0xEC02	valid drive configuration mode, use supported drive mode (Velocity)			
0xEC03	implemotion bus read/write error			
0xEC04	Drive does not support Ethercat feature set			
0xEC05	System init failure			
0xEC06	Communication error			
0xEC07	Drive fault stop			
0xEC08	Drive STO active			
0xEC09	Drive in permanent stop mode			
0xEC0A	Drive status bits indicate error			
OxECOB	Servo ready status invalid from fast update response			
0xEC0C	Cia402 CSP mode not supported use CSV mode			
0xEC0D	SM Sync not supported, use DC-sync			

If drive fault is active, drive specific error codes are shown directly on error code input.

Drive specific error codes are listed on the following web page: <u>https://granitedevices.com/wiki/Fault\_location</u>

# Troubleshooting



LED	LED	LED	LED	Descption
1	2	3	4	
		Blin k	Blin k	When LED1 & LED2 blinks at startup constantly the number of drives found does not mismatch the drives configured with rotary switch. Please check drive count with Granity tool and select correct drive count with rotary switch